


RTL* scale installation tool (A-9589-0420)

A-9589-0420 RTL* scale installation tool is used as an aid to insert RTL scale through the FASTRACK™ carrier system.


NOTE: Refer to the relevant readhead installation guide for specific *FASTRACK* installation instructions.


Tool identification:


RTLA/RTLC/RTLR scale installation tool (A-9589-0420)











Renishaw plc


New Mills, Wotton-under-Edge Gloucestershire, GL12 8JR United Kingdom T +44 (0)1453 524524

F +44 (0)1453 524901

E uk@renishaw.com

www.renishaw.com





For worldwide contact details, please visit our main website at

www.renishaw.com/contact

RENISHAW HAS MADE CONSIDERABLE EFFORTS TO ENSURE THE CONTENT OF THIS DOCUMENT IS CORRECT AT THE DATE OF PUBLICATION BUT MAKES NO WARRANTIES OR REPRESENTATIONS REGARDING THE CONTENT. RENISHAW EXCLUDES LIABILITY, HOWSOEVER ARISING, FOR ANY INACCURACIES IN THIS DOCUMENT.

© 2017-2019 Renishaw plc. All rights reserved.

Renishaw reserves the right to change specifications without notice.

RENISHAW and the probe symbol used in the RENISHAW logo are registered trade marks of Renishaw plc in the United Kingdom and other countries. apply innovation and names and designations of other Renishaw products and technologies are trade marks of Renishaw plc or its subsidiaries. All other brand names and product names used in this document are trade names, trade marks registered trade marks of their respective owners.



M-9589-9101-01

Part no.: M-9589-9101-01-B Issued: 11.2019